



MOUNT THE BRACKETS

BEFORE YOU BEGIN

You need to determine what type of surface you are mounting your bracket to. Predrill using the brackets as a guide. Ensure you use appropriate plugs and masonry tools if mounting into brick or stone.

TIMBER

We recommend predrilling holes and use 25mm button head screws

PLASTER

We recommend a wall anchor.

STONE, CONCRETE, BRICK, TILE

Use a masonry drill with appropriate screws, anchors and plugs

Simply rest the L bracket on top of the architrave ensuring it is mounted onto a secure stud.

Secure brackets with one screw only, once satisfied with position proceed to secure brackets in place using the second screw.

INSTALL THE PELMET

Lift the pelmet over the L brackets then drill through the L bracket into the pelmet.

