MOUNT THE BRACKETS

BEFORE YOU BEGIN

Check your 'Measure' sheet to determine the configuration of the blind.

You need to determine what type of surface you are mounting your bracket to. Predrill using the brackets as a guide. Ensure you use appropriate plugs and masonary tools if mounting into brick or stone. It's best to install brackets on studs if possible.

TIMBER

We recommend a wall anchor.

PLASTER

STONE, CONCRETE, BRICK, TILE Use a masonry drill with appropriate

screws, anchors and plugs

We recommend predrilling holes and use 25mm button head screws

There needs to be a maximum 300mm between brackets to ensure the strength of the blind. Secure brackets with one screw only, once satisfied with position proceed to secure brackets in place using the second screw. Make sure to mount brackets where they will not interfere with vertical mechanisms.

INSTALL - FACE FIT

Screw clip into blacket, ensuring clips face the same direction.

Push lip of the track in and then rotate the other into place.

Simply feed slat into runners lean on a slight angle and the slat will sit inside the hook. And then hang the wand if ordered.

Screw in Clip

Screw in Clip

Fit Track to Clip

Fit Track to Clip

Fit Track to Clip

INSTALL - RECESS FIT

Screw clip into the recess, ensuring clips face the same direction.

Push lip of the track in and then rotate the other into place.

Simply feed slat into runners lean on a slight angle and the slat will sit inside the hook. And then hang the wand if ordered.

INTALL THE SAFETY CLIP

A child safety clip must be installed if the chain sits lower than 1.6 metres from the floor.

We here at **Blinds On Demand** take the safety of our kids very seriously.

Fit the chain into the loop of the clip. Pull the clip down until it is as tight as possible without placing tension on the chain. Screw into place.







blindsondemand.com.au



TICK IF FACE FIT





