



MOUNT THE BRACKETS

BEFORE YOU BEGIN

Check your 'Measure' sheet to determine the configuration of the blind

You need to determine what type of surface you are mounting your bracket to. Pre-drill using the brackets as a guide. Ensure you use appropriate plugs and masonry tools if mounting into brick or stone.

TIMBER

We recommend predrilling holes and use 25mm button head screws

PLASTER

We recommend a wall anchor.

STONE, CONCRETE, BRICK, TILE


Use a masonry drill with appropriate screws, anchors and plugs

Secure brackets with one screw only, once satisfied with position proceed to secure brackets in place using the second screw.

ROLL TYPE




OVER ROLL




UNDER ROLL

FIT TYPE



RECESS FIT



FACE FIT

INSTALL THE BLIND



Put the pin end in first.

While maintaining slight tension on the pin end side, lift the clutch end side and align the two hooks with the two vertical slots on the bracket.


The blind should lower into place.

CLUTCH END


PIN END



Pin end in



Align two hooks



Blind in place






INSTALL THE SAFETY CLIP

A child safety clip must be installed if the chain sits lower than 1.6 metres from the floor.

We here at **Blinds On Demand** take the safety of our kids very seriously.

Fit the chain into the loop of the clip. Pull the clip down until it is as tight as possible without placing tension on the chain. Screw into place.



WARNING



WARNING: Young children have died by wrapping loose curtain and blind cords or chains around their necks. Secure cords or chains with cord guides or keep them out of reach by winding them around a cleat. Move cots and furniture away from window covering cords or chains. Do not remove this label.

